

**AutoDome Commands**

<b>FUNCTION</b>	<b>COMMAND</b>	<b>NOTE</b>
<b><i>Pre-position Commands</i></b>		
Pre-position Menu	SET 100 ENTER	
Pre-position Set/Show	SET/SHOT 1-99 ENTER	4,11
Edit Pre-position Title On/Off	ON/OFF 62 ENTER	
Edit Preposition Tour On/Off	SET/SHOT 900 ENTER	
Home Position Recalibrate/Set	SET/SHOT 110 ENTER	11
Move Pan Position 180°	SHOT 111, 180 ENTER	10
Factory Default Settings	SET 899 ENTER	9,11
Global Pre-position Disable/Enable	SET/SHOT 900 ENTER	10,11
Pre-position Disable/Enable	SET/SHOT 901-999 ENTER	6,10,11
<b><i>Standard R/D Commands</i></b>		
Scan On/Off	ON/OFF 1 ENTER	5
Auto Pan On/Off	ON/OFF 2 ENTER	
Auto Pan Left Limit Set/Show	SET/SHOT 101 ENTER	2,11
Auto Pan Right Limit Set/Show	SET/SHOT 102 ENTER	2,11
Pre-Position Tour On/Off	ON/OFF 8 ENTER	
Record Tour A On/Off	ON/OFF 100 ENTER	
Record Tour B On/Off	ON/OFF 101 ENTER	
Erase Tour Recording to End	SET 500 ENTER	11
Playback, Continuous, Start/Stop	ON/OFF 50 ENTER	
Playback, Single, Start/Stop	ON/OFF 51 ENTER	
Resume Playback	ON 52 ENTER	
Record	ON/OFF 100 ENTER	10
Resume Record	ON 101 ENTER	10
<b><i>Advanced R/D Commands</i></b>		
(Tour stuff)		
AutoPivot™ On/Off	ON/OFF 18 ENTER	
Zone Title Edit On/Off	ON/OFF 63 ENTER	
<b><i>Lens Commands</i></b>		
Auto Focus On/Off	ON/OFF 12 ENTER	2
Focus Control Auto/Manual	ON/OFF 4 ENTER	1
Iris Control Auto/Manual	ON/OFF 3 ENTER	1
Auto Iris On/Off	ON/OFF 13 ENTER	2
Zoom Ratio Limit/Full	ON/OFF 19 ENTER	2
<b><i>Camera Commands</i></b>		
Command Lock Mode Activate	SET 103 ENTER	10,11
Command Lock Mode Deactivate	SET 104 ENTER	10,11
Backlight Compensation On/Off	ON/OFF 20 ENTER	1
Highlight On/Off	ON/OFF 21 ENTER	1
View Factory Default Settings On/Off	ON/OFF 47 ENTER	
View Software Version On/Off	ON/OFF 66 ENTER	
<b><i>Advanced Commands</i></b>		
On Screen Display Menu On/Off	ON/OFF 60 ENTER	
FastAddress™ Edit	ON 999 ENTER	
Display FastAddress™	ON 997 ENTER	

## AutoDome Commands

FUNCTION	COMMAND	NOTE
<b>Day/Night Commands (Day/Night Models Only)</b>		
Day/Night Mode Menu On/Off	ON/OFF 56 ENTER	
Night Mode On/Off	ON/OFF 57 ENTER	
Night Mode Threshold Adjust	ON 58 ENTER	
Day/Night Mode Quick Set Select Menu	ON 59 ENTER	

### NOTE INDEX:

1. This setting is stored with pre-position.
2. This setting is stored as a default setting in non-volatile memory (EEPROM) on the R/D board and is used to restore settings at power-up.
3. This setting is stored as a default setting in the camera's non-volatile memory.
4. Pre-position #1 (if set) is automatically called-up upon power-up just after the homing sequence.
5. The scan direction is determined by the last manual pan direction.
6. Pre-positions can be disabled such that they do not operate during and automatic call-up (tour). They are still available for manual call-up.
9. This command clears all pre-positions, resets the EEPROMs to factory defaults, and resets the lens and camera to default settings.
10. Access to certain AutoDome commands can be restricted when using an Allegiant switching system. Allegiant system operators with Priority levels 1 through 7 can activate the 'command lock' mode by 'setting' pre-position 103. Once the lock mode is activated, Allegiant system operators with priority level 8 would not be able to change functions indicated by note 10. The higher priority operators (1 to 7) can deactivate the 'command lock' mode by 'setting' pre-position 104.
11. Allegiant operators with priority level 8 are not permitted to 'set' pre-position functions.